

## Pour 'N Store Dispenser Assembly Instructions



**1.** Expand 8-sided corrugated tube and fold in spout flap. Turn tube over (as shown) and begin bottom assembly.



**2.** Fold the rounded die-cut flaps toward the interior of the tube.



**3.** Fold up the 8 flaps of the bottom cap (bottom cap does not have die-cut spout cutout).



**4.** Insert bottom cap with flaps upward.



**5.** Make sure all tabs on the bottom cap flaps are inserted into the slots on the rounded interior tube flaps.



**6.** Fold over the 8 rectangular flaps at the end of the tube and lock tabs into the slots in the bottom cap.



**7.** Turn tube over and partially fill with product if desired. Filling above the bottom edge of the spout flap in tube may make final assembly difficult.



**8.** Fold down the rounded die-cut flaps of the tube, and fold up the flaps of the top cap as was done previously.



**9.** Align top cap spout cutout with V-shaped score lines on spout flap in tube.



**10.** Insert top cap with flaps upward and ensure that all tabs are locked into the slots of the rounded flaps of the tube.



**11.** Fold over the 7 rectangular flaps at the end of the tube and lock tabs into the slots in the top cap.



**12.** Pop out and remove the die-cut spout cutout from the top cap. (Utility knife may be used if necessary.)



**13.** Reach through spout cutout and fold up spout flap along the V-shaped score lines.



**14.** Pull folded spout flap up through spout cutout in top cap.



**15.** Re-flatten spout along V-shaped score lines. Fill or complete filling dispenser with product. Your dispenser is now ready for use.

**Associated  
Bag Company**



**800-926-6100**  
[www.associatedbag.com](http://www.associatedbag.com)